

RETRODECK INSTALLATION STEPS

Follow steps 1 thru 8 to install the RetroDeck 8" or RetroDeck 12" Dish and Antenna Mounting System.

**STEP
1**



Locate truss with stud finder, lift shingles with prybar at dish location, do not lift middle row

**STEP
2**



Before screwing base plate to roof, align both base & deck plate to assure shingles will fall into place

**STEP
3**



Install base plate with trusshead screws

**STEP
4**



Install foot on deck plate using cap bolts

**STEP
5**



Slide deck under top shingle and seat over base

**STEP
6**



Use Tek Screws to secure deck to base plate

**STEP
7**



Install deck plate using trusshead screws, use small amount of roof cement under top shingle to secure

**STEP
8**



COMPLETED INSTALL