


## SPECIFICATION

Furnish and install Tech Specialties Copper Roof Side-Outlet with Overflow Drain and flashing area in one unit, all manufactured by Tech Specialties or approved equal.

# ACCEPTANCES/LISTINGS

Plumbing Safety I.A.P.M.O. - File Number 2998. SBCC Report# 9831A



PART NO.

T-0250

T-0251

**MATERIAL FEATURES** 

Noncorrosive plastic grate and adapter clampEntire drain and flange is made with 100% copper

ADDITIONAL DESIGN FEATURES

Sand blasted flange finish for excellent asphalt adhesion.
Excellent adhesion to torch-applied, modified roof systems

No-hub adaptor is made of 100% brass.


Roof drain available in 2" and 3" pipe sizes.


• Drain and flange size is 18" W x 24" L.

• 52 square inches of open area on grate.

• Round 10" seamless drain basin.

and B.U.R. systems.





**COPPER ROOF SIDE-OUTLET** 

WITH OVERFLOW DRAIN

**Specification Sheet** 

DESCRIPTION

2" Copper Roof Side-Outlet w/Overflow Drain 3" Copper Roof Side-Outlet w/Overflow Drain



Product Submittal	
Job Name	
Date	
Part Number	Quantity
Architect	
Contractor	




3689 Arrowhead Drive, Carson City, NV 89706 Phone (800) 854-3215 Fax (800) 243-1777 E-mail sales@lspproducts.com Website www.lspproducts.com

Content matter is subject to change at any time. It is the user's responsibility to ensure the most updated revisions are obtained.

TS/S-2011 (5-05) Rev 2



# COPPER ROOF SIDE-OUTLET WITH OVERFLOW DRAIN Specification Sheet



### FLASHING DETAIL FOR BUILD-UP ROOF SYSTEMS


- Mechanically attach 2 plies of roofing base ply sheet embedded in hot asphalt to substrate, ensure the plies extend 18" past underlying portion of drain flange.
- 2. On under portion of drain flange embed, 1/3" layer, evenly spread roofing mastic compound.
- 3. Securely fasten drain flange to substrate, using appropriate fasteners.
- 4. For best results, prime drain flange with asphalt primer. Allow ample drying time.
- Begin B.U.R. system embedding alternate layers of roofing ply sheet in a feathering application down into sump and over flange. Note: Ensure asphalt is at a temperature range between 430°F and 475°F.
- Secure adapter clamp and grate in place with provided hardware.
- 7. Complete roof system with specified surfacing as required


## FLASHING DETAIL FOR MODIFIED SINGLE-PLY ROOF SYSTEMS


- Place reversed sheet of modified over drain hole opening on substrate. Ensure that ply sheet extends 18" past underling portion of drain flange. Note: Recommend asphalt primer on under portion of drain flange be applied beforehand.
- 2. Place drain on hot modified ply and secure drain flange to roof substrate using appropriate fasteners.
- 3. For best results, prime top portion of drain flange with asphalt primer. Allow ample drying time.
- 4. Back burn modified ply sheet, start roof system and down into sump receiver and over flange.
- 5. Secure adapter clamp and grate into place with provided hardware.
- 6. Complete modified single-ply system with specified surfacing as required.

## FLASHING DETAIL FOR E.P.D.M. OR RUBBER SINGLE-PLY ROOF SYSTEMS

- 1. Place single-ply sheet over drain hole on substrate. Ensure that ply sheet extends 18" past underlying portion of receiving drain flange.
- 2. On under portion of drain flange embed 1/3" of water stop cut off.
- 3. Securely fasten drain flange to substrate using appropriate fasteners.
- 4. Embed single-ply sheet in specified adhesive down into sump and over top portion of the flange.
- 5. Secure adapter clamp and grate in place with provided hardware.
- 6. Complete single-ply system with specified surfacing as required.









3689 Arrowhead Drive, Carson City, NV 89706 Phone (800) 854-3215 Fax (800) 243-1777 E-mail sales@lspproducts.com Website www.lspproducts.com

Content matter is subject to change at any time. It is the user's responsibility to ensure the most updated revisions are obtained.

TS/S-2011 (5-05) Rev 2